



Dr. Fixit Pidicrete MPB

ACRYLIC MULTI PURPOSE BINDER

Description

Dr. Fixit Pidicrete MPB is composed of acrylic co-polymer emulsions & additives. It is used as bonding agent for new to old substrates & cement mortar modifier because it provides strong bonds to old & new concrete. Improves tensile & flexural strength of concrete and increases the durability of the structure. When mixed with cement, It forms a matrix & provide excellent waterproof coating.

Areas of Application

- **Concrete repair** - spalled concrete, floor, columns, beams, chajja, slab & parapet etc.
- **Bond coat** - Old to new concrete, masonry, stonework plaster, fixing or re-fixing slip bricks, tiles, marbles & bedding.
- **Priming** - Reinforcement steel.
- **Additive** - Additives for renders & mortars.
- **Coating** - As an flexibiliser to cement.

Features & Benefits

- **Chloride content** - Contains no chloride all.
- **User friendly** - Single component ready to use, simply brushed onto concrete as a primer.
- **Bonding** - Provides excellent bond to concrete, masonry, Stonework, plywood, gypsum & plaster.
- **Strength** - Improves tensile, flexural and compressive strength as compared to control concrete hence increases the durability of structures.
- **Compatibility** - Compatible with all common cements hence it is versatile.
- **Dust generation** - Excellent as a dust proof sealer
- **Waterproofing** - Improves waterproofing properties & cement & cementitious compositions.
- **Flexibility** - Improve flexural strength of cement & cementitious composition.

Method of Application

1 SURFACE PREPARATION

- Clean the surface and remove any dust, unsound or contaminated material, loose plaster, oil, paint, grease, corrosion deposits or algae. Where breaking out is not required, roughen the surface and remove any laitance by light scabbling or grit blasting.
- Expose fully the corroded steel in the repair area and remove all loose scale and corrosion deposits. Steel should be cleaned to bright condition particularly the hidden portions of the exposed steel bars

2 APPLICATION

Reinforcing steel priming

- Apply one coat of Dr. Fixit Pidicrete MPB mixed cement slurry (1:1 by volume) to all exposed steel reinforcement and allow it to dry. A second coat application is also recommended. Allow it to dry. The surface should be thoroughly soaked with clean water prior to application of Dr. Fixit Pidicrete MPB.
- Apply Dr. Fixit Pidicrete MPB with brush or rollers on the substrate and avoid ponding and remove any excess material. The repair or topping application should be carried out whilst the primer is still tacky.

Render and Mortars

A suitable mix ratio for patching repair mortar or render. Mix design - Portland Cement : 50 kg, Washed sand : 150 kg & Dr. Fixit Pidicrete MPB : 20 litres. Sufficient water can be added to give the required consistency

Bonding Slurry Coat

- Mix Dr. Fixit Pidicrete MPB with cement where extra adhesion is required.
- Recommended mix shall be 10 litres of Dr. Fixit Pidicrete MPB mixed with cement in the ratio 1:1 by volume.

Waterproofing With cement as an additive for achieving waterproofing

Curing

- Cure the repaired area by using Dr. Fixit Pidicrete MPB to prevent rapid loss of water. In severe drying conditions additional curing methods may also be necessary.
- Protect uncured mortar from frost and rain.

Technical Information

PROPERTIES	Specification	RESULTS
Appearance		Milky white liquid
Chloride content		Nil
PH		7.0 - 8.0
Compressive strength, N/mm ²	BS 6319 Part 2: 1983	Dry condition: 30-40
Wet Condition: 25-30		
Adhesion strength, concrete, dry condition, N/mm ²	BS 6319 Part 4:1984	5-20
Curing efficiency, %	BS 7542:1992	>55

Coverage

As coating: Approximately 5-7 m²/litre

Packaging

4 & 20 litres

Shelf Life & Storage

- Best before one year from the date manufacture when in sealed pack and stored under proper condition.
- Store in a cool & dry place in unopened condition away from direct sunlight



Health & Safety Precautions

- Dr. Fixit Pidicrete MPB is non-flammable.
- Wear suitable protective clothings, gloves, eye protection and respiratory protective equipment during application.
- In case of contact with skin, rinse with plenty of clean water and then cleanse with soap water.
- In case of contact with eyes, rinse immediately with plenty of clean water and seek medical advise.

Other Products Categories available

Dr. Fixit brings the widest range of Construction Chemicals



Pidilite Industries Limited

Construction Chemicals Division
 Ramkrishna Mandir Road, Post Box No. 17411
 Andheri (E) Mumbai 400059 INDIA
 Tel +91-22-2835 7000 • Fax +91-22-2835 7008
 www.doctor-fixit.com • drfixitadvice@pilmail.com

Dr. Fixit Advice Centre (Toll Free No.) 1800-209-5504

DISCLAIMER The product information & application details given by the company & its agents has been provided in good faith & meant to serve only as a general guideline during usage. Users are advised to carry out tests & take trials to ensure on the suitability of products meeting their requirement prior to full scale usage of our products. Since the correct identification of the problems, quality of other materials used and the on-site workmanship are factors beyond our control, there are no expressed or implied guarantee / warranty as to the results obtained. The company does not assume any liability or consequential damage for unsatisfactory results, arising from the use of our products.